


1.2 Cable for Download


■ Download via COM Port

RS-232


DOP series HMI 9 pin D-SUB male (RS-232)	PC 9 pin D-SUB female (RS-232)	Controller
RXD (2)	(3) TXD	
TXD (3)	(2) RXD	
GND (5)	(5) GND	
RTS (7)	(8) CTS	
CTS (8)	(7) RTS	



D-SUB 9pin to DOP series (male)



D-SUB 9pin to PC (female)



■ Download via USB Flash Drive

USB Connection



USB TAPE B to DOP series



USB TAPE A to PC

